


# BOWHOUSE COMMUNITY CENTRE



# BOWHOUSE COMMUNITY CENTRE

## **Stage Dimensions**

Proscenium opening - 23 ft 6 ins  
Depth to proscenium opening - 19 ft  
Depth to front of stage - 23ft  
Access to stage from FOH steps at SR and SL.

## **Tabs**

Front tabs are red – pulley system at stage right  
Running black tabs between LX 1 and LX 2 – pulley system  
Drawn black tabs between LX 3 and LX 4 - manual  
Drawn black tabs before the cyclorama wall – manual  
4 pairs of adjustable black legs

## **Lighting**

Three colour cyc available at LX4  
Nine areas available on stage using FOH 1 and LX 1, LX 2 and LX 3  
Three non-adjustable specials SR, Centre and SL from FOH 1.  
Specials can be set anywhere else on stage before and between performances given time constraints  
Side lighting available between LX 1 and LX 2 and also between LX 2 and LX 3.  
FOH 2 provides warm or cold wash crosswise to stage right or stage left or both. - all other gels are coloured Lavender or Light Lavender  
Lighting control of the 24 × 2 kW dimmer rack by ZERO 88 Jester and operation can be manually scene-by-scene, submaster or by memories as required.